

theLeda S10 W WH

theLeda S10 W BK

theLeda S20 W WH

theLeda S20 W BK

307286 03

#### **Basic safety information** 1.

1020931

1020932

1020933

1020934

#### WARNING

Danger of death through electric shock or fire! > Installation should only be carried out by a qualified electrician!

Only intended for installation out of arm's reach.

- High temperature! Do not touch the metal parts of the device.
- ① The LED spotlight with motion detector (PIR) conforms to EN 60598-1 and EN 60669-2-1 if correctly installed
- ① IP 55 in accordance with EN 60529
- ① Optional with corner angle (9070969/9070987) and distance frame (9070971/9070988)

#### 2. Proper use

- LED spotlight is used for lighting, depending on presence and brightness
- Device is for wall mounting inside and outside
- For entrances, garages, gardens, corridors, parks, etc.
- For use in normal ambient conditions
- ① Lamp cannot be replaced.

Replace entire spotlight if defective!

### Disposal

> Dispose of device in environmentally sound manner


## 3. Connection



#### 

Danger of death through electric shock or fire! > Installation should only be carried out by a qualified electrician!

- > Disconnect power source!
- > Ensure device cannot be switched on!
- > Check absence of voltage!
- ► Earth and bypass
- > Cover or shield any adjacent live components




## Installation

## Installation instructions




### WARNING

- Danger of death through electric shock or fire! Installation should only be carried out by a qualified electrician!
- ① Observe the recommended installation height of 1.8 m-2.5 m!




As the LED spotlight reacts to variations in temperature, avoid the following situations:


- ① Do not direct the LED spotlight at objects with highlyreflective surfaces such as mirrors etc.
- ① Do not install the LED spotlight near heat sources, such as heating outlets, air conditioning systems, lamps etc.
- ① Do not direct the LED spotlight at objects that move in the wind, such as curtains, large plants etc.
- ① Pay attention to the direction of motion during the test run




> Disconnect power source




> Use spacer or corner bracket (optional)




 Loosen catch mechanisms with a screwdriver and remove LED spotlight from base




> Make marks for the holes and drill the holes




> Guide wire through the socket's seal; fix socket to the wall




 Fix socket to wall, connect the individual wires to the appropriate terminal and tighten screws



> Place and engage the LED spotlight on the base




➤ Connect LED spotlight to mains




① The detector needs approx. 40 s of preheating time.

## 5. Description



The LED spotlight has 3 potentiometers for setting time (min), brightness (lux), and function mode.

# 6. Aligning the LED spotlight



① Settings via poti are taken after 15 s

## Setting the brightness (LUX)



- Turn the potentiometer towards "Moon"; the LED spotlight only switches on when it is relatively dark.
- Turn the potentiometer towards "Sun"; the LED spotlight switches on when it is relatively bright
- Turn the potentiometer to "Sun", and the device works independent of brightness

### Setting the time (TIME)



> Set the potentiometer to the desired time (2 s - 30 min)

#### Function mode (MODE)




- Turn the potentiometer to "auto"; the LED spotlight switches on when there is motion in the dark
- Set Potentiometer to "10 %": LED spotlight switches to the set dimming value when dark
- ▶ (10 % 50 %) for for movement to 100 %.

#### Manual operation

The lighting can be switched on manually via a circuit breaker button.

O A circuit breaker button must be connected

① Function only possible at night




- > Quickly confirm Circuit breaker 2 x (within 2 s)
  - ightarrow The lighting remains switched on for 6 hours.
- To switch off the lighting and return to auto mode, press the circuit breaker briefly (within 2 s)
- If the circuit breaker is pressed x2 during this six second turn-on time, the lighting is switched on again for 6 hours.

## 7. Walking test

The walking test is used to test the detection area and to restrict it if necessary.

- ➤ Set potentiometer "brightness" to "sun".
- ➤ Set the time potentiometer (TIME) to "test".
  - → The motion detector now always reacts to movements (independent of brightness).
- Walk through the detection area at a right angle. After the motion detector has detected a movement, it switches on for 2 s.


① Pay attention to the direction of motion during the test.





## 8. Aligning the LED spotlight

#### theLeda S10














#### theLeda S20





## 9. Limiting the detection area

- Use enclosed stickers to adjust the motion detector to the desired detection area.
- > Remove the desired part of the cover clip with scissors.
- > Then stick to the lens.



## 10. Technical Data

Operating voltage:	230 V ± 10 %
Frequency:	50-60 Hz
Consumption with light On:	10 W / 2 x 10 W
Standby output:	0.5 W
Colour rendering index:	85
Service life:	L80/B10 20.000 h
Protection rating:	IP 55 in accordance with EN 60529
Protection class:	I in accordance with EN 60598-1
Operating temperature:	−20 °C +45 °C
Brightness setting range:	2 – 200 lx / ∞ lx
Duty cycle range:	2 s – 30 min
Detection angle:	180°
Detection area: lateral:	max. 10 m
frontal:	max. 4 m
Colour temperature / LED output	1020931-1020934:
(luminous flux):	3000 K / 850 lm (2 x 850 lm) 1020921-1020924:
	4000 K / 850 lm (2 x 850 lm)
Mass/dimensions:	1020921+1020922: 313 g/
	80 x 160 x 50 mm
	1020923+1020924: 463 g/
	167 x 160 x 50 mm
	1020931+1020932: 313 g/ 80 x 160 x 50 mm
	1020933+1020934: 463 g/
	167 x 160 x 50 mm

## 11. Contact

Theben AG Hohenbergstr. 32 72401 Haigerloch GERMANY Phone +49 7474 692-0 Fax +49 7474 692-150

#### Hotline

Phone +49 7474 692-369 hotline@theben.de Addresses, telephone numbers, etc. www.theben.de